

- NEO GLASS cannot be placed in the following location, even if set up with ADA aquarium cabinet.
- Carpet floor or tatami mat room
- Vibration-sensitive place (For example, the second floor could be inappropriate in terms of building construction).
- Locations which receive direct sunlight, or the place with extremely high or low humidity. Placing the NEO GLASS in the open air accelerates the deterioration of the silicon, and shortens the aquarium tank life cycle.
- Locations with high temperature variation range, such as place near the air conditioner.
- Locations near home electric appliances (Water splash from the aquarium tank may trigger electrical shock).
- Locations in the reach of child
- Handle with care, and do not give vibration or shock from outside.
- When handling the NEO GLASS, make sure to carry by holding the bottom of the tank with empty condition.
- Do NOT move the NEO GLASS filled with water or set with substrate.
- Before placing the NEO GLASS on top of the aquarium cabinet, confirm the top is clear. Even small gravel could become the cause of cracking of the aquarium glass.
- Do NOT pour hot water (over 40 degrees Celsius) into the NEO GLASS. Please also avoid direct contact with aquarium heater. Sudden temperature change may cause cracking of the glass.
- Do NOT use detergent or organic solvent solution for cleaning purpose. Those materials could deteriorate the silicon. Use dry, soft cloth for cleaning the NEO GLASS.
- During the maintenance of the aquarium, please pay attention not to cause any scratch on the glass with gravels. When removing the algae on the glass surface with scraper, be careful not to give damages to the silicon.
- Do NOT use basic organic dyes in the NEO GLASS. It may deteriorate the silicon.
- Do NOT modify the NEO GLASS.
- Do NOT use the NEO GLASS if its silicon joint is deteriorated or detached.

中文

1. 使用之前

※使用本产品前, 请一定阅读以下的注意事项。

- 在使用新水陆玻璃缸及新悬浮玻璃缸之前, 请仔细阅读本说明书。请在理解了正确的使用方法后再进行使用。在不知道正确使用方法的情况下, 严禁使用。
- 请确认本说明书中填写的购买日期, 经销商名称等必要事项并在仔细阅读后妥善保存本说明书。
- 请一定在确认了鱼缸各个连接部位的硅胶没有异常后再进行使用。产品的初期不良大多可以在使用前发现, 可以避免漏水等事故的发生。
- 硅胶中的气泡不影响其强度。
- 新水陆玻璃缸及新悬浮玻璃缸作为鱼缸, 具有足够的强度。但由于是玻璃制品, 其有抗碰撞能力及抗歪斜能力较低的特性。请务必在使用时遵守下列注意事项。对由于没有正确使用所引起的产品的损坏或事故, 弊社不承担任何责任。

2. 使用注意事项

- 请购买弊社的底柜, 或在具有足够强度的, 没有歪斜的平面上放置新水陆玻璃缸及新悬浮玻璃缸。摆放前请务必使用水平仪确认鱼缸摆放位置没有歪斜现象。鱼缸的开裂问题主要是摆放位置或底柜歪斜所引起的。弊社对于鱼缸开裂问题不承担任何责任。
- 为了安全使用, 请在鱼缸底部铺设减少底柜歪斜度的橡胶垫或防震垫。推荐我们为您准备的适合各种鱼缸尺寸的专用减震底垫。
- 请不要把鱼缸放置于书桌, 鞋柜等各种不是鱼缸的专用底柜上面。即使下面铺设了板子, 也不要把鱼缸直接摆放在地面上。
- 即使使用了弊社专用的底柜, 下面几种地方也严禁放置鱼缸。
 - 铺设了榻榻米或地毯的房间 (下面铺设了板子也不能放置)
 - 容易产生振动的地方 (例如: 两层建筑的二楼等, 在建筑结构上被认为不适合的地方)
 - 直射阳光的地方, 湿度极高或极低的地方, 屋外等 (造成硅胶加速老化, 鱼缸寿命缩短的重要原因)
 - 空调暖气的附近等温度变化大的地方
 - 家用电器的附近 (溅到水会有漏电的危险)
 - 孩子的手能够摸得到的地方 (鱼缸有被碰撞, 摔落, 导致鱼缸破裂的危险)
- 请轻拿轻放, 严禁晃动或给予鱼缸冲击, 会造成破损。
- 搬运鱼缸时, 必须保持里面是空的状态。请托底部搬运。

- 严禁在鱼缸中有水或砂砾, 泥土等的状态移动鱼缸。
- 在放置鱼缸前, 请仔细检查鱼缸底面 (与鱼缸底面接触的底柜表面), 确保没有任何砂砾等异物。即使有一粒沙子, 也会造成鱼缸破损的原因。