

- ○両側のロックを押し込んでからホールキャップを外します。吸気の場 合は別売のサーキュレーションファン 40 (別売) の矢印を下向きに、 排気の場合は上向きにして設置してください。
- ○サーキュレーションファン 40 (別売) の固定パーツを外して本体をガラ スフタの穴に差し込み、反対側から固定パーツを差し込んでください。



# 吸气:

水槽外の湿度の低い空気を 内部に引き込みます。



#### 排気: ▮

水槽内の湿った空気を 外に洮がします。 吸気に比べて湿度変化が 緩やかになります。

お問い合わせ先:ADAサービスセンター 0256-72-1994(平日10:30~17:30) E-mail/support@adana.co.ip

発売元: 株式会社 アクアデザインアマノ 新潟県新潟市西蒲区漆山8554-1 〒953-0054

#### aoua pesigo amago colto

8554-1 Urushiyama, Nishikan-ku, Niigata 953-0054, Japan





# NEO GLASS COVER

for CIRCUI ATION FAN 40 ネオグラス ガラスフタ サーキュレーションファン 40対応 使用説明書


#### ●安全 Fの注意


a platform allowing everyone to nurture plants indoors Feel closer to nature, and bring beauty into your life.

- ○本製品は、植物の育成を目的に開発された製品です。この目的以外に は使用しないでください。
- ○ガラスフタには、それぞれ適合する水槽サイズがあります。使用前に確 認してください。
- ○この製品はガラス製のため、落として衝撃を加えたり、不用意に力を加 えると破損するおそれがあります。水槽にセットする際や取り外す際は、 特にご注意ください。
- ○製品が破損した場合は、ケガをしないように注意して取り扱い、危険 物として処分してください。
- ○破損の原因となりますので、洗浄の際に熱湯を使用しないでください。
- ○子どもの手の届かない場所で使用および保管してください。
- ○水に濡れると滑りやすくなりますので、ご注意ください。

#### ●使用方法

○滑り止めシールの剥離紙をはがし、図を参考にして水槽に接地する面 (ロゴシールを貼っていない面)の四隅に貼ってください。





※シールの位置が水槽に触れるように 静かにのせてください。


#### **English**

### Safety Instruction


- This product has been developed for the purpose of growing plants. Do not use this product for any other purpose.
- Each glass cover has a compatible aguarium size. Check before use. This product is made of glass and may be damaged if dropped and impacted or if force is applied carelessly. Be especially careful when
- setting or removing the product to/from the aguarium. Olf the product is damaged, handle it with care to avoid injury and
- dispose of it as hazardous waste.
- ODo not use boiling water when cleaning the product, as it may cause damage.
- OKEEP OUT OF REACH OF CHILDREN.
- OBe aware that the product becomes slippery when wet.

# DUsage

- OPeel off the release liner of the anti-slip strip, and affix the anti-slip strip to the four corners of the surface (the side without the logo sticker) that touches the aquarium, referring to the illustration.
- \*Gently place the glass cover so that the anti-slip strip touches the aguarium.




- OPush in the locks on both sides and remove the hole cap. For air intake, place the Circulation Fan 40 (sold separately) with the arrow facing downwards, and for air exhaust, place it facing upwards.
- Remove the fixing part of the Circulation Fan 40 (sold separately). insert the main unit into the hole in the glass cover, and insert the fixing part from the opposite side.



# Air intake:

Low humidity air from outside the aquarium is drawn into the inside of the aquarium.



## Air exhaust :1

Humid air inside the aquarium escapes to the outside. Humidity changes more slowly than air intake