


---

---

---

Top glass plate 60\*      Outflow pipe x1      Fan mounting hole + Hole cap



\*Neo Glass Paluda 30 and 60 accessories: Sliding glass top, Top glass plate, Hole cap x 1, Drainage piece, spare acrylic screw x 2/each size, spare metal screw x 1, spare hinge shaft x 1

---

② **Placing Paluda Clean PC /** It is an exchangeable absorption pack that removes dissolved calcium and magnesium from the water with the function of cation

③ **Starting the Pump /** Pour water directly into the Mistflow box to the level where the pump is completely sunk in water so that the pump will not run without water. The

• Once you start the pump, make sure of the normal operation of the pump without any troubles including water leakage. If any abnormal symptom is observed, unplug the

④ Mistflow and Mistflow Cap Installation / Attach Mistflow Cap to Mistflow and set it in the circular fitting piece located in the center of the Mistflow tank.

⑤ **Circulation Fan 40 installation / Remove the Hole cap located in the center of the Stainless-steel mesh cover and set the fan into the hole. Fix the fan with the lock piece**

⑥ Drainage piece Installation / Place the Drainage piece

⑦ **Lighting Installation / Install a lighting system compat-**

⑧ Controlling cultivation conditions / With Power Cord

EXCESS WATER ACCUMULATION

WATER CONTROL SYSTEM

• Before use, shake or squeeze Wabi-Kusa Mat lightly (not too hard to avoid deforming the mat) → 

- Use of ADA Terra Line for fixing Willow Moss to Wabi-Kusa Mat is beneficial in maintaining a

• Epiphytes from ADA's Jungle Plant series are great items for paludarium background. When

---

○ Attach a Sponge hook to the High absorbent sponge before use. The sponge gets dirty and clogged over use. Clogged sponge will cause a decline in absorption. Hence,

○Dirt and algae build up on the Cascade spillway. Before water flow is affected by dirt/algae, remove them with Cascade Brush S to keep this part clean.

○Fix Wabi-Kusa Mat in place firmly using the retainer grid pins. System Paluda 30 can hold up to 9 pieces of Wabi-kusa Mat, and System Paluda 60 up to 18 pieces.

○ Separately sold Jungle Soil and Jungle Base of the DOQA Series are recommended as substrate materials to be used for this product.

○ The mist may escape through the gap in the glass door, depending on the installation or the usage conditions of Circulation Fan 40. Use a commercially available U-shape

○ The mist may escape through the gap in the glass door, depending on the installation or the usage conditions of Circulation Fan 40. Use a commercially available O-shape silicone seal if necessary.

silicone seal if necessary.

